

Things to consider when working with Multiwood

- Always keep the Multiwood sheets on a flat surface.
- Multiwood Sheets can be cut into pieces using hand cutter or machine cutter. Keep the cut pieces on top of each other on a flat surface. The sides can be trimmed using sander tool.
- Apply either NC-Putty, Polish-Putty, M-Seal to scrub and sand to smooth it, where the screw holes are located and near the cut parts.
- If you see small scratches on the surface like small lines, level it using Water paper / Sandpaper (220/180). It is beneficial for applying sandpaper in other parts as well for painting or pasting mica, veneer etc..
- It is advisable to use automotive paints and PU based primers manufactured by the major companies in India.
- Before painting cut parts can be joined together using Dry-Wall Full Threaded Screws and glues like Wudfill, Flex Quick etc. from Fevicol company can also be used for joining.
- Use primer before painting. Work with a brush, roller or spray gun. Allow drying time in a clean room or in an open area. Do not try to dry under sunlight.
- For all type of works referred above, always keeping Multiwood straight is advisable. Thomson Multiwood Sheets can make the most beautiful and lasting products in the shortest possible time.

Before starting the work consider the following:

Open the cover and check the sheets thoroughly on both sides. In the case of colour sheets, need to check and make sure that there is no colour variations or scratches found before starting to use. Company shall not be responsible for any complaint raised after cutting the sheets.

one product | many advantages | many applications

LIFE TIME
warranty



100%
Water, Termite
& Borer proof



NO
Shrinking
or swelling



100%
Bacteria &
Fungus resistant




**THE
THOMSON
GROUP**

33 years of pioneering experience

Multiwood Care : 9745112121 | Email : info@thomsonmultiwood.com | web : www.multiwood.in